

Access Charger Wall Mounting Instructions

It is not necessary to disassemble the charger to mount it to a wall or other flush surface. A bracket for this type of mounting is included with each charger. For flush mounting on a flat wall, use the brief directions below.

Mount the bracket shown below securely to your wall. Total weight could be up to 125 lbs per charger.



Be sure to position the “ears” pointing upward and out from the wall.

Hang the charger on the bracket using the slots on the rear “frame rails” of the charger.



Once the charger is hanging from the bracket, mark the position of the lower charger mounting holes on the wall.

Remove the charger and install anchors and/or fasteners on to the wall, re-hang the charger and secure the lower charger holes to the wall with appropriate fasteners .

For mounting on charger stands or battery racks, the available stands can be used, or frequently customers use 2 sections “uni-strut” rails mounted on the stand or rack to mount to the mounting holes on the rear of the charger. The photo below, depicts a small stand that uses uni-strut to mount the charger. Longer sections of uni-strut can be used to mount several chargers side by side. Always be sure to allow 12” between chargers.



DDB
Access mounting.doc